

MODEL POSR-2

PILOT OPERATED PRESSURE REDUCING REGULATOR

SECTION I

I. DESCRIPTION AND SCOPE

The POSR-2 is a pilot operated pressure reducing regulator used to control downstream (P_2) pressure. Sizes are 1", 1-1/2", 2", 3" and 4" (DN25, 40, 50, 80, 100). The unit is suitable for steam service only. Refer to Technical Bulletin POSR-2-TB for design conditions and selection recommendations. **NOT RECOMMENDED FOR DEAD END SERVICE.**

SECTION II

II. INSTALLATION

A. General:

⚠ WARNING

Do not dead end (no flow demand) downstream of POSR-2 if P_1 - Inlet Pressure is greater than maximum allowable outlet design pressure.

Spring Range	Max. Allowable Outlet Pressure
5-15 psig (0.34–1.03 Barg)	100 psig (6.9 Barg)
10-40 psig (0.69–2.8 Barg)	200 psig (13.8 Barg)
30-80 psig (2.1–5.5 Barg)	200 psig (13.8 Barg)
70-150 psig (4.8–10.3 Barg)	200 psig (13.8 Barg)

B. Piping the Valve:

1. An inlet block valve should always be installed.
2. If service application is continuous such that shut down is not readily accomplished, it is recommended that an inlet block valve, outlet block valve, and a manual bypass valve be installed.
3. Pipe unions are recommended for NPT screwed installations to allow removal from piping.
4. An outlet pressure gauge should be located approximately ten pipe diameters downstream, and within sight.
5. All installations should include a downstream relief device if the inlet pressure could exceed the pressure rating of any downstream equipment or the maximum allowable outlet pressure rating of the unit.




FIGURE 1

Recommended Piping Schematic for POSR-2

⚠ CAUTION

Installation of adequate overpressure protection is recommended to protect the regulator from overpressure and all downstream equipment from damage in the event of regulator failure.

⚠ CAUTION

For welded installations, all internal trim parts, seals and diaphragm(s) must be removed from regulator body prior to welding into pipeline. The heat of fusion welding will damage non-metallic parts if not removed. NOTE: This does not apply to units equipped with extended pipe nipples.

6. Clean the piping of all foreign material including chips, welding scale, oil, grease and dirt before installing the regulator. Strainers are recommended.



CAUTION

DO NOT HYDROSTATIC TEST THROUGH AN INSTALLED UNIT, INCLUDING PILOT; ISOLATE BOTH PILOT AND MAIN VALVE FROM TEST. The upper range spring pressure level listed on the nameplate is the recommended “upper operative limit” for the sensing diaphragm(s) in the pilot. Higher pressures could cause internal damage. In addition, note on the nameplate that the Inlet and Outlet pressure and temperature ratings are at different levels.

7. In placing thread sealant on pipe ends prior to engagement, assure that excess material is removed and not allowed to enter the regulator upon start-up.
8. Flow Direction. Install so the flow direction matches the flow arrow on the body.
9. The POSR-2 comes factory piped between the pilot supply and pilot loading. Install an external sensing line from the 1/4" NPT connection opposite the factory piped pilot loading port to a point downstream at gauge location; use 1/4" OD metal tubing for distances 4 ft (1.2 m) or less, and 3/8" OD metal tubing (requires 1/4" x 3/8" tubing adapter) for distances greater than 4 ft. (1.2 m). The sensing line should always be sloped downward so that condensation will drain away from the pilot. If regulator pipe line is expanding to a larger pipe line, always connect sensing line to the larger pipe line.

10. See Figure 2 for installation orientation for horizontal or vertical piping. For best performance Cashco recommends installing in a well drained horizontal pipe, properly trapped.

Position “H”: Horizontal Pipe. Requires user to install sensing line on downstream piping.

Position “VD”: Vertical pipe with downwards flow direction. Requires user to install sensing line on downstream piping.

Position “VU”: Vertical pipe with upwards flow direction. Pilot valve and main valve shipped as separate units. Requires user to install pilot valve at downstream pipe tap with a pipe nipple (not provided), provide and install tubing (4 tube fittings and two 4 ft (1.2 m) lengths of 1/4" OD copper tubing supplied) to loading chamber tap and to P₁ body tap from pilot valve.

11. Recommended installation is with pilot valve spring chamber vertical upwards. Orient such that the spring chamber vent hole does not collect rainwater or debris.
12. Regulators are not to be buried underground.
13. For insulated piping systems, recommendation is to not insulate regulator.

SECTION III



III. PRINCIPLE OF OPERATION

A. General:

1. The POSR-2 pilot obtains its operating medium from the main valve body inlet. Downstream pressure (P₂) registers on the underside of the main valve's piston and the pilot valve's diaphragm(s).
2. The loading pressure on the top side of the main valve's piston is an intermediate pressure higher than the downstream (P₂) pressure by the sum of the pressures required to overcome the main valve's plug unbalance force and the piston spring's force.
3. The pilot has a bleed orifice that continuously bleeds part of the loading medium downstream. In operation, the pilot valve's plug can flow more medium than is bleeding downstream.

This increases the loading pressure on the main valve's plug and opens valve. Partially closing the pilot valve's plug will reduce its flow to less than the amount bleeding downstream, and allows the loading pressure on the main valve's piston to decay, allowing partial closing of the main valve's plug. This continues until steady-state is developed.

4. The pilot valve's diaphragm(s) senses the downstream (P₂) pressure and compares the force generated to the force developed by the pilot's range spring.
5. If, during operation, the downstream (P₂) pressure falls below the pilot valve's setpoint, the main valve's piston senses the reduced pressure on its underside and instantly moves down, increasing the flow through the main valve. At the same time, the pilot valve senses the reduced pressure and the pilot valve's

 Pipe or tubing installed by customer / installer.
 Pipe or tubing installed by Cashco.




FIGURE 2
Orientation/Arrangement

plug increases its opening, elevating the loading pressure on the upper side of the main valve's piston. The combined actions increase flow enough to restore the downstream (P_2) pressure to the setpoint.

6. If the downstream (P_2) pressure rises above the setpoint, the force developed by the increased pressure on the underside of the piston instantly moves it upward and partially closes the main valve's plug. Simultaneously, the pilot valve's plug partially closes and allows the loading pressure to decay through the

bleed orifice. The reduced loading pressure on the upper side of the piston closes the main valve's plug enough to restore the downstream (P_2) pressure to the setpoint.

7. Pressure setpoint is adjusted by changing the compression of the pilot's range spring by turning the adjusting screw either clockwise (CW) or counter-clockwise (CCW). Turning the adjusting screw clockwise (CW) will increase the downstream (P_2) pressure. Turning the adjusting screw counter-clockwise (CCW) will decrease the downstream (P_2) pressure.

SECTION IV

IV. START-UP

A. General

1. Start with the block valves closed.
2. Ensure that the needle valve(s) on the sensing line is opened and downstream (P_2) pressure is indicating on pressure gauge.
3. Relax the pilot valve range spring by turning the adjusting screw counter clockwise (CCW) (viewed from above) a minimum of three (3) full revolutions. This reduces the outlet (downstream) pressure setpoint.
4. Slowly open the bypass valve to preheat the system piping and to allow slow expansion of the piping. Assure proper steam trap operation. Closely monitor outlet (downstream) pressure via gauge to assure not over-pressurizing.
NOTE: *If no bypass valve is installed, extra caution should be used in starting up a cold system; i.e. do everything slowly.*



CAUTION

Do not walk away and leave a bypassed regulator unattended when on manual bypass!

If not, slightly close bypass valve, and then slowly rotate the pilot valve adjusting screw clockwise (CW) (viewed from above) until flow begins.

7. Continue to alternate slowly closing the bypass valve and then slowly opening the inlet (upstream) block valve, especially when the downstream piping system isn't pressurized. If the outlet (downstream) pressure exceeds the desired pressure, close the bypass valve until fully closed. If outlet pressure still remains above desired level, rotate pilot's adjusting screw CCW (viewed from above) in 1/2 revolution increments until outlet pressure reaches desired level. If outlet pressure is below desired level, rotate pilot's adjusting screw CW (viewed from above) until desired level is reached.
8. When flow is established steady enough that the inlet (upstream) block valve is fully open, begin to slowly close the bypass valve and continue until fully closed.
9. Develop system flow to a level near its expected normal rate, and reset the regulator setpoint by turning the pilot valve adjusting screw CW (viewed from above) to increase outlet pressure, or CCW to reduce outlet pressure.
10. Reduce system flow to a minimum level and observe setpoint. Outlet pressure will rise from the setpoint of Step 9. There should be no more than a 10% variation in outlet pressure over the maximum to minimum flow range.

5. Slowly open the outlet (downstream) block valve until fully open. Slightly close the bypass valve at same time.
6. Slowly open the inlet (upstream) block valve observing the outlet (downstream) pressure gauge. Determine if the regulator is flowing.

SECTION V

V. SHUTDOWN

A. General

1. On systems with a bypass valve, and where system pressure is to be maintained as the POSR-2 is shut down, slowly open the bypass valve while closing the inlet (upstream) block valve. Fully close the inlet (upstream) block valve. (When on bypass, the system pressure must be constantly observed and manually regulated.) Close the outlet (downstream) block valve. Close the needle valve on the pilot valve's sensing line.

CAUTION

Do not walk away and leave a bypassed regulator unattended!

2. If the regulator and system are to both be shutdown, slowly close the inlet (upstream) block valve. Close the outlet (downstream) valve only if regulator removal is required. Close the needle valve on the pilot valve's sensing line.

SECTION VI

VI. MAINTENANCE

CAUTION

SYSTEM UNDER PRESSURE. Prior to performing any maintenance, isolate the regulator from the system and relieve all pressure. Failure to do so could result in personal injury.

A. General:

1. Maintenance procedures hereinafter are based upon removal of the regulator unit from the pipeline where installed, and maintenance performed in a workshop.
2. Owner should refer to owner's procedures for removal, handling, cleaning and disposal of nonreusable parts, i.e. gaskets, etc. Cashco recommends not reusing any gaskets, but replacing with only new and factory supplied gaskets.
3. This regulator is supplied from the factory using a gasket sealing aid, Federal Process Company, PLS2, or equal. Such compatible sealing aids may be utilized by the Owner, if desired.
4. All indicated item numbers that are with respect to the Pilot Valve will be in parenthesis and underscored, i.e. (14), (PV). All item numbers that are with respect to the Main Valve will **NOT** be underscored, i.e. (1), (MV).
5. Refer to Figures 6 through 12 for item number callouts.

B. Separation:

1. Observe orientation of pilot valve (PV) with respect to main valve (MV) position "VD", "H", or "VU", Figures 6, 7 or 8, before disassembling.
2. Place main valve body (1) into a vise, oriented to allow rotation of pilot valve (PV) together with interconnecting pipe nipple (19).
3. Remove loading tubing (21) at both end fittings (20) by rotating nut CCW (viewed from tube-end). Disengage union (28) where applicable and remove pilot valve (PV).
4. Place pipe wrench on pipe nipple (19) and rotate CCW (viewed from pilot valve (PV) end) to removal. Remove main valve (MV) from vise and set aside.
5. Place pilot valve body (1) in vise. Remove pipe nipple (19) or other pipe fittings (20, 27, 30) as is applicable.
6. Inspect the inside of the pipe and fittings for corrosion, scaling, debris, or filming. Problems here will be an indication of improper condensate corrosion control which can affect the overall operation of the POSR-2. Install an upstream strainer if scale or debris appears at this point.

7. Remove pilot valve (PV) from vise and set aside.

C. Pilot Valve (PV):

1. Securely install the pilot valve body (1) in a vise with the spring chamber (2) directed upwards.



WARNING

SPRING UNDER COMPRESSION. Prior to removing body flange bolts, relieve spring compression by backing out the adjusting screw. Failure to do so may result in flying parts that could cause personal injury.

2. Loosen locknut (20) by rotating CCW (viewed from above) **ONLY** two revolutions. Relax range spring (15) by turning adjusting screw (19) CCW (viewed from above) until removed from spring chamber (2). Set adjusting screw (19) with locknut (20) aside.
3. Draw or embed a match mark between body casting (1) and spring chamber casting (2) along flanged area.
4. Remove all diaphragm flange nuts (18) and bolts (17).
5. Remove spring chamber (2) by lifting upwards. Remove range spring (15) and spring button (16).
6. Remove pressure plate (14). Inspect to ensure that the pressure plate (14) has not been deformed by overpressure by placing a thin, straight bar or ruler across the side that touches the diaphragm (12). If the pressure plate (14) does not touch the bar at its center (i.e. a depression in center), the pressure plate (14) is deformed and must be replaced.
7. **NOTE:** Pilot valves (PV) supplied with a 5–15 psig (0.34–1.03 Barg) range spring (15) have only one diaphragm (12) supplied; all other spring ranges use two diaphragms (12).

Using a putty knife or similar tool, remove diaphragm(s) (12) and diaphragm gasket (13). Inspect diaphragm(s) (12) for cracks or deformation. Radial creases and cracks indicate overpressure. Cracks circumferentially indicate high cycles, and may be due to normal cycling, or pulsing or chattering if premature. Discard both diaphragm(s) (12) and gasket (13).

8. Using a 7/8" deep well socket, remove bellows (11) by rotating CCW (viewed from above). Count and record the number of revolutions required to remove the bellows (11) in the box below:

Number of revolutions required to remove bellows (11): _____.

Inspect the bellows (11) for a crack or joint failure where leakage is occurring. Replace bellows (11) if leaking.

9. Remove protruding stem extension (10).
10. Using a flat, sharp-edged tool, clean body (1) flange where diaphragm gasket (13) seals.
11. Using a wire gauge tool, clean the 0.068" (1.73 mm) diameter bleed orifice located in the body cavity (smaller of two holes) of any film or other buildup material that might be restricting flow.

***NOTE:** Any significant blockage of the bleed orifice will downgrade a POSR-2's performance. If a buildup is forming, attempt to determine the cause and remove the source.*
12. Remove body (1) from vise and reorient with body cap (9) on top; resecure body (1) in vise.
13. Remove body cap (9) by rotating CCW (viewed from above) with hex-end wrench. Hammer-rapping the wrench may be necessary, as the body cap (9) has a metal-to-metal shoulder joint with the body (1). **NOTE:** Plug (4.2) and plug spring (7) may come out with body cap (9) removal.
14. Remove plug spring (7) and plug (4.2) from body (1) recess.
15. Using needle nose pliers, carefully remove the screen (6) from the body (1) recess.
16. Inspect body cap (9), screen (6), plug spring (7), and plug (4.2) for buildup or filming. If parts are "sticking" together, then improper condensate corrosion treatment is likely. If scale or other debris is present, then an upstream strainer is recommended.
17. Using a 5/8" deepwell socket, rotate valve seat (4.1) CCW (viewed from above) to removal.
18. Remove seat gasket (8) using a tool with a bent sharp end. Discard the seat gasket (8).

19. Using a sharp edged tool, clean all gasket surfaces, and metal-to-metal contact surfaces of body (1), valve seat (4.1) and body cap (9).
20. Lap plug (4.2) with valve seat (4.1) using a suitable lapping compound. Do for new replacement plug (4.2) and seat (4.1) also.
21. Solvent clean all loose internal parts of pilot valve (PV). Inspect the valve seat (4.1) and plug (4.2) for wear. Replace the valve seat (4.1) and plug (4.2) together, even if only one piece shows significant wear. Solvent clean body (1).
22. Place body (1) into vise with body cap (9) opening upwards.
23. Place seat gasket (8) into recess.
24. Put thread lubricant onto valve seat (4.1), and rotate valve seat (4.1) into threaded recess by rotating CW (viewed from above) until seat (4.1) shoulders against body (1).
25. **NOTE: Replace screen (6) only if necessary.** Using a 3/4" (19 mm) round bar, form and interlock the flat screen (6) similar to the removed screen (6) being replaced. Slide formed screen (6) off of bar. Insert the screen into the body recess and over the hex points of the valve seat (4.1). Ensure concentricity of positioned screen (6).
26. Place plug spring (7) into recess of plug (4.2), and position plug's (4.2) stem-end through the valve seat (4.1).
27. Place thread lubricant on threads of body cap (9). Capture protruding plug (4.2) end and plug spring (7) with body cap (9) recess. Rotate body cap (9) CW (viewed from above) until shouldering on body (1). Hammer rap wrench handle to ensure tightness.
28. Remove body (1) from vise and reposition with diaphragm flange oriented on top.
29. Place thread sealant/lubricant onto threads of bellows (11). Insert flat-end of stem extension (10) into the center of the bellows (11); chamfered end of stem extension (10) should be protruding bellows (11). Invert bellows (11) with stem extension (10) into body (1) recess. Allow stem extension (10) to "fall" into threaded opening for bellows (11). Align threaded portion of bellows (11); rotate CW (viewed from above) the same number of engaged revolutions recorded in article 8. previous, this subsection.
30. Place diaphragm gasket (13) onto body's (1) flange aligning cutouts of gasket (13) with bolt hole openings.
31. Place diaphragm(s) (12) onto body (1) positioned concentrically. **NOTE: Reassemble pilot valve (PV) ONLY with the number of diaphragms (12) disassembled with; the 5–15 psig (0.34–1.03 Barg) spring range uses only one diaphragm (12).**
32. Concentrically position pressure plate (14) onto diaphragm(s) (12).
33. Set range spring (15) over hub of pressure plate (14).
34. Place multi-purpose, high temperature grease into recess of spring button (16) where adjusting screw (19) bears. Place spring button (16) over top-end of range spring (15) with greased recess on top side.
35. Clean threads of diaphragm bolting (17) (18). Place thread lubricant on bolts (17). Engage two sets of bolting (17) (18) for ease in rotation; disengage.
36. Place the two bolts (17) of above approximately 180° across through body (1) diaphragm flange from underneath side. Hold bolts (17) with fingers of one hand to keep from falling downwards.
37. Set spring chamber (2) down over the two protruding bolts (17), aligning the matchmarks of article 3. previous, this subsection.
38. Place the two nuts (18) onto bolts (17) of above, and finger-tighten.
39. Place remaining bolts (17) through spring chamber (2) bolt hole openings. Engage all nuts (18) onto bolts (17) along underneath side of body (1) flange and finger-tighten.
40. Remove the two upside-down bolts (17) and nuts (18) and rotate to position of other bolts (17). Place nameplate tag (21) over one of the bolts (17) before replacing into bolt hole. Finger-tighten nuts (18).
41. Observe through opening in top of spring

chamber (2) to ensure the concentricity of the recess in the spring button (16) with the top opening. It may be necessary to use an awl or similar tool to realign the spring button (16) as much as possible. The spring chamber (2) is not tightened down, and may be temporarily “shifted” to help ensure alignment for the adjusting screw (19) engagement.

42. Place lubricant onto the upper exposed threads of the spring chamber’s (2) adjusting screw (19) opening. Place lubricant onto the adjusting screw (19) lower-end threads. Engage adjusting screw (19) back into spring chamber (2) by rotating CW (viewed from above). Engage only until resistance is made with the range spring (15) via the spring button (16).
43. Realign the spring chamber (2) flange with the body (1) flange, and wrench-tighten bolting (17, 18) in an alternating, crossing pattern. Final tightening should be done with a torque wrench to 15 ft.-lbs. (20 N-M).

⚠ WARNING

Never replace bolting (17, 18) with just any bolting if lost. Bolt heads and nuts are marked with specification identification markings. Use only proper grades as replacements.

44. Continue CW rotation (viewed from above) of adjusting screw (19) until locknut (20) touches spring chamber (2). Back adjusting screw (19) out by rotating CCW (viewed from above) two revolutions. This position will approximate the pressure setpoint prior to disassembly if the locknut (20) is only loosened two revolutions as directed in article 2. previous, this subsection.
45. Reconnect pilot valve (PV) to main valve (MV). See Figures 6, 7 and 8 for correct orientation. Pressure leak test the complete assembly per Section VII.D.

D. Main Valve (MV):

1. General Note: The actuator/topworks section of the main valve (MV) is sufficiently “heavy” for the 3” and 4” (DN80 and 100) body sizes that the procedures following are written to include overhead hoisting. Additionally, following the procedure will ensure that the internals subassembly (IS) will not “fall from within the cylinder (3)” when the cylinder (3)

is oriented vertically, when gravity overcomes seal (12) friction.

⚠ WARNING

Follow procedures given herein in handling main valve topworks! Failure to heed may result in internals sliding out of cylinder and falling downwards to impact on foot!

For the 1” through 2” main valve (MV) body sizes, the actuator/topworks is not so heavy that an overhead hoist is required. However, if an overhead hoist is not used, improper handling of the removed cylinder (3) and internals subassembly (IS) can still result in the internals subassembly (IS) “falling from within the cylinder (3)” by gravity, so the above “warning statement” is still valid.

2. Using an overhead hoist, rig the main valve (MV). Lift and securely place the main body (1) in a vise with the cylinder head (4) directed upwards.
3. Draw or embed a match mark between the cylinder head (4), cylinder (3), bonnet (2) and body (1).
4. Loosen elongated cylinder bolting (16, 17) by rotating each nut (17) CW (viewed from above) until fully removed. Withdraw each of the four elongated bolts (16). **NOTE:** *Sizes 3” and 4” (DN80 and 100) have the body’s (1) bonnet flange drilled and tapped so that no bottom nut (17) is required.*
5. While holding the cylinder (3) by hand, use a wooden block to lightly rap the underneath side of the cylinder head (4) to release the head-to-cylinder joint. Once loosened, remove the cylinder head (4).
6. Place locking pliers on stem nut (15). Keep the pliers within the cylinder’s (3) interior away from the cylinder (3) wall.
7. While placing downward force on the locking pliers of the previous article, grasp the cylinder (3) by hand and simultaneously lift upwards and wiggle sideways at the top until the joints at the lower end of the cylinder (3), bonnet (2) and body (1) loosen. If necessary, use a flat, sharp-edged tool to get under the bonnet (2) at the joint between the bonnet (2) and the body (1) while gently pushing the cylinder’s (8) upper edge sideways back-and-forth; do not apply excessive sideways force to the

cylinder (3). Move the flat tool fully around the bonnet-to-body joint to ensure being fully loosened.

8. Install the temporary eyenut (supplied with Parts Kits "A" or "B" for 2"–4" sizes) onto the threaded end of the plug-stem assembly (7). Eyenut size is:

Main Body Size	Nominal Eyenut Size - Inch
2"	1/2" – 13 UNC
3"	1/2" – 13 UNC
4"	5/8" – 11 UNC

NOTE: For the 1" and 1-1/2" main valve (MV) body sizes, fabricate a hanger bracket with sheet metal similar to Figure 3 below.




FIGURE 3
Hanger Bracket

9. Using an overhead hoist with the cable, rope, etc., fastened through the temporary eyenut, pull the internals subassembly (IS) and cylinder (3) upwards and out of the body (1). The internals subassembly (IS) consist of the following parts:

- (2) bonnet
- (5) seat ring
- (7) plug-stem assembly
- (8) piston
- (12) piston seal
- (13) one-ring gasket
- (14) piston spring
- (15) stem nut

10. Position the hoisted internals subassembly (IS) and cylinder (3) above a second vise with leaded jaws. Lower the suspended parts such

that the outer diameter edge of the bonnet (2) can be secured in the vise, and the plug-stem assembly (7) oriented horizontally. When secured, slacken overhead hoist cable, rope, etc., to allow removal.

11. Remove temporary eyenut from end of plug-stem assembly (7).
12. Place a support strap around the cylinder (3) and attach to overhead hoist. Place the strap into "tension" with the hoist by removing "slack" in strap.
13. Insert a "round" tool (rod, Allen key wrench, Phillips-end screwdriver, etc.) through the hole located in the stem portion of the plug-stem assembly (7), just above the plug portion.
NOTE: It may be necessary to place a wrench on the stem nut (15) to rotate the plug-stem assembly (7) enough to allow access for the round tool through the "cage window" of the bonnet (2) and through the stem (7) hole.
14. Loosen stem nut (15) by rotating CCW (viewed from nut end), allowing tool of previous article to secure the plug-stem assembly (7) from rotating. Fully remove stem nut (15). **NOTE:** There will be noticeable friction in removal of nut (15) as piston spring (14) relaxes (elongates). The spring (14) will be fully relaxed before the stem nut (15) is fully removed.
15. Pull cylinder (3) horizontally outwards to removal, moving overhead hoist as necessary. Set cylinder (3) aside.
16. Using a needle-nose pliers, grasp outside lip of seal (12), lift seal (12) up and pull out of recess over end of piston (12). **NOTE:** Seal (12) should be replaced with every disassembly.
17. Remove piston (8) and piston spring (14).
18. While holding seat ring (5) with fingers, withdraw plug-stem assembly (7). Seat ring (5) will be released from capture.
19. Remove all three of the TFE gaskets (13) and discard. These gaskets may be stuck to the cylinder head (4), cylinder (3), bonnet (2) or body (1). If any of these gaskets (13) were leaking, determine by inspection the possible reason for the leakage.
20. Remove seat ring gasket (6) from body (1) cavity and discard.

21. Using a sharp, flat-edged tool, clean the gasket facings and all surfaces where a metal-to-metal joint occurs on the body (1), bonnet (2), cylinder (3) and cylinder head (4).
22. Remove body (1) and bonnet (2) from vises and solvent clean. Solvent clean all loose parts to be reused.
23. Inspect all surfaces for wear. Replace all parts that have excessive wear. Replace seat ring (5) and plug-stem assembly (7) as a set. Hone cylinder (3) if slightly grooved.
24. Lap plug-stem assembly (7) together with seat ring (5) using a suitable lapping compound. Do for new replacement parts as well as reused parts (5, 7). Clean parts of lapping compound with suitable solvent and let dry.
25. Place cleaned body (1) back into vise.
26. Place new seat ring gasket (6) into body (1) cavity.
27. Insert the plug-stem assembly (7) through the bonnet (2) and check clearance between stem (7) and hardened bushing (18) with a wire gauge. Normal clearance is .001–.002" (.025–.050 mm). If excess clearance is due to wear in stem (7), replace plug-stem assembly (7). If clearance is due to bushing wear, place bonnet (2) under a hydraulic press and "press out" the bushing (18); "press in" a replacement bushing. If new bushing seems "loose" after pressing in, place four small tack welds along the bushing (18) OD on top of bonnet (2)-to-bushing (18) joint, taking care to not overheat the bushing (18) and distort.
28. Place bonnet (2) back into the second vise held as previous.
29. Determine correct orientation of seat ring (5) from Figure 9 herein. **(DO NOT INSTALL SEAT RING (5) UPSIDE DOWN.)** Insert plug-stem assembly (7) threaded end through seat ring (5) and bonnet (2) bushing (18). Push seat ring (5) into the "cage" portion of the bonnet (2).
30. Place TFE ring gasket (13) onto upper side of bonnet (2) and onto shoulder.
31. Place a thin film of lubricant onto the cylinder (3) inside wall at the wear points of the piston seal (12). Wipe excess lubricant away with a clean, dry cloth.
32. Place cylinder (3) into a strap support and lift with an overhead hoist. Swing cylinder (3) over threaded end of plug-stem assembly (7) and lower into the shoulder of bonnet (2), taking care to protect ring gasket (13) of previous article 30., above. Align match marks and apply duct tape to hold cylinder (3) to bonnet (2).
33. Place piston (8) with recess for piston spring (14) face down on flat surface.
34. Position a small section of the seal (12) circumference around the top recess of the piston (8). Apply an equal amount of thumb pressure on opposing sides of the seal (12) as the seal (12) is pressed around and over the top of the piston (8) into the recess. NOTE: Install seal (12) with opening of U-Cup facing upwards.
35. Place piston spring (14) into recess of piston (8).
36. Rotate stem (7) until the tool of previous article 13., this subsection, can be inserted through hole of stem (7). Leave the tool in the hole.
37. Carefully slide piston (8) with captured piston spring (14) into cylinder (3). Insert a rod or similar tool into the center hole of the piston (8), and simultaneously lift and move into the cylinder (3) deeper. Using fingers of one hand, push the plug-stem assembly (7) together from the plug (7) end. Lift piston (8) onto threaded portion of plug-stem assembly (7) as far as possible, removing tool when necessary. Place hand into cylinder (3) and push the piston (8) until the piston spring (14) begins to compress.
38. Place temporary eyenut onto threaded end of plug-stem assembly (7). Finger-tighten eyenut until piston spring (14) is slightly under compression.
39. Place a rope, cable, etc., through the eyenut and rig for overhead lifting. Simultaneously, loosen the grip of the vise on the bonnet (2), lift the cylinder (3) with its hoist, and lift the partial internals subassembly (IS) with its hoist. Continue the lifting slowly until the internals subassembly (IS) is vertical. Release the strap support from the cylinder (3). Fully release the vise's grip.
40. Place a round wooden peg about 2" (50 mm) tall with flat ends, and small enough to fit within the seat ring (5) onto a flat work surface. Swing

partial assembly of previous article above until centered over the peg. Lower partial assembly down onto peg until weight is resting on peg. Place spacers near outside diameter of bonnet (2) 180° across to stabilize partial assembly from tipping over. See Figure 4.




FIGURE 4
Wooden Pegs and Spacers

41. Remove overhead support from eyenut. Remove eyenut.
42. Engage stem nut (15) with stem (7) end and rotate nut (15) CW (viewed from above) about two revolutions while restraining with tool to prevent stem (7) rotation.
43. Remove the duct tape applied in previous article 32., this subsection. Grasp the cylinder (3) near its upper edge, and gently wiggle the stacked internals subassembly (IS) parts from several directions.
44. Continue to wrench-tighten stem nut (15).
45. Place duct tape 360° around the cylinder (3)-to-bonnet (2) joint.
46. Install temporary eyenut onto protruding threads of plug-stem assembly (7). Install cable, rope, etc., to overhead hoist.
47. Raise internals subassembly (IS) with cylinder (3) above wooden peg. Remove peg. Lower internals subassembly (IS) and cylinder (3) down onto the flat work surface.

48. Remove temporary eyenut.
49. Place wrench back onto stem nut (15). While grasping anti-stem rotation tool, hammer rap nut (15) tightly. Remove anti-rotation tool.
50. Place temporary eyenut back onto threaded end of plug-stem assembly (7). Re-rig to overhead hoist.
51. Lift the internals subassembly (IS) and cylinder (3). Place a suitable thread sealant in three or four places along the bottom shoulder of the bonnet (2) where the bonnet (2)-to-body (1) ring gasket (13) is located. Push the ring gasket (13) into the sealant expecting the sealant to hold the gasket (13) for final assembly and alignment; apply additional sealant if necessary.
52. Swing lifted internals subassembly (IS) and cylinder (3) over the body (1) in its vise. Align match marks and lower the internals subassembly (IS) downwards into the body (1) cavity, taking care to not damage the bonnet (2)-to-body (1) ring gasket (13). Remove overhead rigging and temporary eyenut.
53. Prepare cylinder head (4) for its ring gasket (13) similar to ring gasket (13) for bonnet (2) of previous article 33., this subsection.
54. Align match marks and lower cylinder head (4) down onto cylinder (3) upper shoulder, taking care to not damage cylinder (3)-to-cylinder head (4) ring gasket (13). Align the flat edges of the cylinder head (4) to be in the same plane as the flange of the body (1) below by rotating the head (4) as necessary.
55. Insert the four elongated cylinder bolts (16) through the bolt hole of the cylinder head (4) and downwards through the bolt hole of the body (1) flange. Install nuts (17) on the bolts (16) by rotating nuts (17) CCW (viewed from above). Finger tighten all nuts (17).

⚠ WARNING

Never replace bolting (17, 18) with just any bolting if lost. Bolt heads and nuts are marked with specification identification markings. Use only proper grades as replacements.

56. Using a torque wrench, tighten the bolting (16, 17) to the levels indicated in the following table in an alternating, crossing pattern in 1/4 revolution increments.

Main Valve Body Size		Torque	
in	(DN)	ft-lbs	(N-M)
1"	(25)	25–30	(33-40)
1-1/2"	(40)	25–30	(33-40)
2"	(50)	70–75	(94-101)
3"	(65)	100–110	(135-149)
4"	(100)	150–160	(203-216)

57. Rig the reassembled main valve (MV) for overhead hoisting. Remove temporary duct tape. Lift and remove from vise.

E. Joining:

1. Place main valve body (1) into vise, oriented to allow correct positioning of pilot valve (PV) and interconnecting piping. See Figures 6, 7 & 8.

2. Place thread sealant on threaded ends of pipe nipples (19, 29 and 30) and on street elbow (27). Ensure that excess material is removed and not allowed to enter the regulator upon start-up.
3. Reconnect pilot valve (PV) to main valve (MV) using appropriate pipe nipple(s) and fittings (19, 26, 27, 28, 29 & 30). Using a pipe wrench, ensure that all connections are tight and in proper orientation.
4. Reinstall interconnecting tubing (21) between main valve (MV) cylinder head (4) and pilot valve (PV) body (1).
5. Leak test the combined unit per Section VII.D.

SECTION VII

VII. LEAK TESTING

A. General:

1. A POSR-2 is a metal-to-metal seated design with standard hardened trim in main valve (MV) and pilot valve (PV).
2. Both pilot valve (PV) and main valve (MV) are of a flow-to-close design, and can be seat leakage tested without extensive setup.
3. There are two design pressures for a POSR-2; one for the higher inlet pressure zone, and another for the lower outlet pressure zone.

Recommended Test Pressures –

Inlet: 100 psig (7.0 Barg).

Outlet: 15 psig (1.03 Barg) for Pilot with 5–15 psig (0.34–1.03 Barg) spring range.

Outlet: 40 psig (2.7 Barg) for Pilots with (Cont.) 15–150 psig (1.03–10.3 Barg) spring ranges.

B. Seat Leakage – Pilot Valve (PV):

1. Separate pilot valve (PV) from main valve (MV), see Section VI, subsection B.
2. Install a temporary 1/4" - NPT pipe plug into the (P_{int}) connection.

3. Install a hose fitting and hose into the 1/2" FNPT connection port of the pilot valve (PV) body (1). Place other "open" end of the hose at the bottom of a glass container having approximately 1/8" (3 mm) of water depth. **NOTE:** Pilot valve (PV) and glass container should be at about the same elevation.
4. Relax the range spring (15) by rotating the adjusting screw (19) CCW (viewed from above adjusting screw) until fully loose. Keep track of the number of revolutions in the box below:

No. of Revolutions adjusting screw rotated:

5. Connect temporary air supply with in-line adjustable airset regulator to P₂ outlet of pilot. Slowly pressurize the pilot valve (PV) while observing the jar with water. Bring pressure to 50 psig (3.4 Barg). Wait a minimum of five minutes. Observe for leakage of bubbles in the water jar. If the number of bubbles is greater than one (1) per minute, the leakage is at the point where trim replacement is recommended. (Recommend pressure integrity test per subsection D. herein.)
6. Remove leak test apparatus. Reconnect pilot valve (PV) to main valve (MV) using appropriate pipe nipples, tubing and fittings (19, 20, 26, 27, 28, 29 & 30). Ensure all connections are tight and in proper orientation.

C. Seat Leakage – Main Valve (MV):

NOTE: The main valve's (MV) plug (7)-to-seat (5) leakage and cylinder (3)-to-seal ring (12) leakage should both be tested.

1. Separate pilot valve (PV) from main valve (MV). See Section VI, subsection B.
2. Insert tapped pipe plugs with hose fittings into both the inlet and outlet connections. Place open end of outlet hose in jar of water per B.3. above.
3. Install temporary hoses with tight shutoff instrument needle valves at three connections; cylinder head-inlet, vent, and inlet of main valve. See Figure 5.
4. Close valves #2, and #3. Open valve #1. Slowly pressurize the inlet up to 50 psig (3.4 Barg). Wait a minimum of 10 minutes. Observe for leakage of bubbles in the water jar. If the number of bubbles is greater than the limit indicated below in Table 1, trim replacement or extra lapping is recommended.

TABLE 1			
Body Size		Maximum Leak Rate	
		Plug-to-Seat Ring	Cylinder-to-Seal Ring
in.	(DN)	SCFH	Bubbles Per Minute
1"	(25)	2	<1
1-1/2"	(40)	4	<1
2"	(50)	7	1
3"	(80)	13	1–3
4"	(100)	17	3–6

5. Remove hose from open end of jar. Open valve #2. Close valve #1. Place hose end back into jar. Follow a similar procedure as in article 4. previous, to leak test the Cylinder (3)-to-Seal Ring (12) seal. (If a new seal ring (12) was installed, stroke the piston (8) about 50 cycles by alternately opening/closing valves #2 and #3 in sequence, attempting to "seat" the seal ring (12) before beginning the leak test.) (Recommend pressure integrity test per subsection D. herein.)
6. Remove leak test apparatus. Reconnect pilot valve (PV) to main valve (MV) using appropriate pipe nipples, tubing and fittings (19, 20, 26, 27, 28, 29 & 30). Ensure all connections are tight and in proper orientation.




FIGURE 5:

D. Pressure Integrity Leak Test:

1. Test pilot valve (PV) and main valve (MV) assembled together with all interconnecting pipe (19), tubing (21) and fittings (20).
2. Insert tapped pipe plugs with hose fittings to both inlet and outlet body (1) connections.
3. Install temporary hoses with tight shutoff instrument needle valves at outlet connection of main valve (MV) and of the pilot valve (PV).
4. Connect temporary air supply with in-line adjustable airset regulator to inlet connection of main valve (MV).
5. Close needle valve at outlet connection of main valve (MV). Crack open the needle valve at the pilot valve (PV) outlet.
6. Rotate adjusting screw (19) of pilot valve (PV) CW (viewed from above adjusting screw) until a point of high resistance occurs; this should correspond to the diaphragm (12) pushing against the body's (1) down travel stops. Record the number of revolutions the adjusting screw was rotated in the box below:

No. of revolutions the adjusting screw was rotated _____.

7. Slowly pressurize the inlet of the main valve (MV) and pilot valve (PV) to 100 psig (6.9 Barg).
NOTE: If the pilot valve (PV) has any other range spring (15) above 5–15 psig (.34–1.03 Barg), the test pressure can be raised to 200 psig (13.8 Barg).

8. Using a solution of leak detection fluid and water, apply a liberal amount of the solution to cover each external joint, including the threaded fittings (20), tubing (21) and the interconnecting pipe nipple (19) threaded connections. Wait a minimum of five minutes to allow sufficient time for a leak to form bubbles. Repeat this procedure with a second five minute wait.

9. Identify and mark any observed leakage. Disassemble down to the point of leakage and determine the cause of the leak. Repair and reassemble per instructions in Section VI. Retest per Section VII.

10. Shut off pressure to inlet connection of main valve (MV) and remove all leak testing equipment. Reset the adjusting screw (19) back to its normal setpoint by rotating the screw (19) CCW (viewed from above) the same number of revolutions recorded in Article 6. previous, this subsection.

SECTION VIII

VIII. TROUBLE SHOOTING GUIDE

1. Erratic or Noisy Operation.

Possible Cause	Remedy
a. Wet steam or condensate at the inlet.	a. Install a steam trap on the inlet side of the regulator.
b. Clogged pilot valve screen.	b. Clean or replace. Blowdown inlet drip leg. Install up-stream strainer, if severe.
c. Regulator oversized for flow conditions.	c. Install correct size.
d. Insufficiently sloped line.	d. Move tap from top of pipe to side; or, increase sensing tube to 3/8" OD.

2. Regulator won't maintain downstream set pressure.

Possible Cause	Remedy
a. Valve undersized.	a. Resize based on actual service conditions.
b. Incorrect range spring.	b. Replace range spring.
c. Failed bellows.	c. Replace bellows assembly.
d. Failed piston seal ring.	d. Replace seal ring.
e. Pressure drop less than required 15 or 20 psid (1–1.4 Bard).	e. Contact your Cashco Representative.
f. Insufficiently sloped line.	f. Move tap from top of pipe to side; or, increase sensing tube to 3/8" OD.

3. Leakage through the pilot spring chamber vent hole.

Possible Cause	Remedy
a. Defective diaphragm.	a. Replace diaphragm.

4. Excessive pressure downstream.

Possible Cause	Remedy
a. Main valve or pilot plug not closing.	a. Inspect the seating of the main valve and then the pilot plug seating. Clean or replace. Check seat gaskets; replace.

SECTION IX

IX. ORDERING INFORMATION

NEW REPLACEMENT UNIT vs PARTS "KIT" FOR FIELD REPAIR

To obtain a quotation or place an order, please retrieve the Serial Number and Product Code that was stamped on the metal name plate and attached to the unit. This information can also be found on the Bill of Material ("BOM"). a parts list that was provided when unit was originally shipped. (Serial Number typically 6 digits). Product Code typical format as follows: (last digit is alpha character that reflects revision level for the product).

□□□□ - □□□□ 7 - □□□□□□□□□□

NEW REPLACEMENT UNIT:

Contact your local Cashco Sales Representative with the Serial Number and Product code. With this information they can provide a quotation for a new unit including a complete description, price and availability.

PARTS "KIT" for FIELD REPAIR:

Contact your local Cashco Sales Representative with the Serial Number and Product code. Identify the parts and the quantity required to repair the unit from the "BOM" sheet that was provided when unit was originally shipped.

NOTE: Those part numbers that have a quantity indicated under "Spare Parts" in column "A" reflect minimum parts required for inspection and rebuild, - "Soft Goods Kit". Those in column "B" include minimum trim replacement parts needed plus those "Soft Goods" parts from column "A".


CAUTION

Do not attempt to alter the original construction of any unit without assistance and approval from the factory. All purposed changes will require a new name plate with appropriate ratings and new product code to accommodate the recommended part(s) changes.

If the "BOM" is not available, refer to the cross-sectional drawings included in this manual for part identification and selection.

A Local Sales Representative will provide quotation for appropriate Kit Number, Price and Availability.


The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such product at any time without notice. Cashco does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Cashco product remains solely with the purchaser.




**“VD”
FIGURE 6**

ITEM NO.	DESCRIPTION
----------	-------------

19	Pipe Nipple
20	Tube Fitting
21	Tubing
26	90° Elbow
27	90° Street Elbow
28	Union
29	Pipe Nipple
30	Pipe Nipple



**“H”
FIGURE 7**



**“VU”
FIGURE 8**




FIGURE 9
MV – MAIN VALVE




FIGURE 10
POSR-2 Flanged End Connection

<u>ITEM NO.</u>	<u>DESCRIPTION</u>
1	Body
2	Bonnet
3	Cylinder
4	Cylinder Head
5	Seat Ring
6	Seat Ring Gasket
7	Valve Plug & Stem Assy.
8	Piston
12	Seal
13	Bonnet & Cylinder Gasket
14	Piston Spring
15	Hex. Nut
16	Hex. Head Bolt
17	Hex. Nut
18	Bushing
24	Flange
25	Flange Split Ring
31	Machine Screw

Not Shown on Drawing

22	Nameplate
23	Drive Screw
43	Drive Screw
44	Flow-Arrow




FIGURE 11
PV – PILOT VALVE




FIGURE 12
HANDWHEEL & LOCKING LEVER

<u>ITEM NO.</u>	<u>DESCRIPTION</u>	<u>ITEM NO.</u>	<u>DESCRIPTION</u>
<u>1</u>	Body	<u>13</u>	Diaphragm Gasket
<u>2</u>	Spring Chamber	<u>14</u>	Pressure Plate
<u>4</u>	Plug & Seat Assembly	<u>15</u>	Range Spring
<u>4.1</u>	Valve Seat	<u>16</u>	Spring Button
<u>4.2</u>	Valve Plug	<u>17</u>	Cap Screw
<u>6</u>	Screen	<u>18</u>	Hex. Nut
<u>7</u>	Spring	<u>19</u>	Adjusting Screw
<u>8</u>	Valve Seat Gasket	<u>20</u>	Adjusting Screw Lock Nut
<u>9</u>	Body Cap	<u>21</u>	Nameplate
<u>10</u>	Stem	<u>22</u>	Handwheel
<u>11</u>	Bellows Subassembly	<u>23</u>	Locking Lever
<u>12</u>	Diaphragm	<u>24</u>	Spring Pin
		<u>25</u>	Bleed Orifice



IOM ADDENDUM:

ATEX DIRECTIVE 2014/34/EU and THE EQUIPMENT AND PROTECTIVE SYSTEMS INTENDED FOR USE IN POTENTIALLY EXPLOSIVE ATMOSPHERES REGULATIONS 2016

Cashco declares that the products listed in the table below has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres given in Annex II of the ATEX Directive 2014/34/EU and given in Schedule 1 of The Equipment and Protective Systems Indented for Use in Potentially Explosive Atmospheres Regulations 2016. Compliance with the Essential Health and Safety Requirements has been assured by compliance with EN ISO 80079-36:2016 and EN ISO 80079-37:2016. The product will be marked as follows:

  II 2 G
Ex h IIB T6... T1 Gb
1000ATEXR1 X

The 'X' placed after the technical file number indicates that the product is subject to specific conditions of use as follows:

1. The maximum surface temperature depends entirely on the operating conditions and not the equipment itself. The combination of the maximum ambient and the maximum process medium temperature shall be used to determine the maximum surface temperature and corresponding temperature classification, considering the safety margins described prescribed in EN ISO 80079-36:2016, Clause 8.2. Additionally, the system designer and users must take precautions to prevent rapid system pressurization which may raise the surface temperature of system components and tubing due to adiabatic compression of the system gas. Furthermore, the Joule-Thomson effect may cause process gases to rise in temperature as they expand going through a regulator. This could raise the external surface temperature of the regulator body and the downstream piping creating a potential source of ignition. Whether the Joule-Thomson effect leads to heating or cooling of the process gas depends on the process gas and the inlet and outlet pressures. The system designer is responsible for determining whether the process gas temperature may raise under any operating conditions.
2. Where the process medium is a liquid or semi-solid material with a surface resistance in excess of 1GΩ, special precautions shall be taken to ensure the process does not generate electrostatic discharge.
3. Special consideration shall be made regarding the filtration of the process medium if there is a potential for the process medium to contain solid particles. Where particles are present, the process flow shall be <1m/s (<3.3 ft/s) in order to prevent friction between the process medium and internal surfaces.
4. Effective earthing (grounding) of the product shall be ensured during installation.
5. The valve body/housing shall be regularly cleaned to prevent build up of dust deposits.
6. Regulators must be ordered with the non-relieving option (instead of the self-relieving option) if the process gas they are to be used with is hazardous (flammable, toxic, etc.). The self-relieving option vents process gas through the regulator cap directly into the atmosphere while the non-relieving option does not. Using regulators with the self-relieving option in a flammable gas system could create an explosive atmosphere in the vicinity of the regulator.
7. Tied diaphragm regulators with outlet ranges greater than 7 barg (100 psig) should be preset to minimize the risk that improper operation might lead to an outboard leak and a potentially explosive atmosphere.
8. All equipment must only be fitted with manufacturer's original spare parts.
9. Ensure that only non-sparking tools are used, as per EN 1127-1, Annex A.

	PRODUCT
	31-B, 31-N
	1164, 1164(OPT-45)
	1171, 1171(OPT-45), 1171(CRYO)
	2171, 2171(OPT-45), 2171(CRYO), 3171
	1465, 3381, 3381(OPT-45), 3381(OPT-40)
	4381, 4381(OPT-37), 4381(CRYO), 4381(OPT-45), 5381
	MPRV-H, MPRV-L
	PBE, PBE-L, PBE-H
	CA-1, CA-2
	CA1, SA1, CA4, SA4, CA5, SA5
	DA2, DA4, DA5, DA6, DA8
	DA0, DA1, DAP, SAP
	SLR-1, SLR-2, PTR-1
	ALR-1, ULR-1, PGR-1
	BQ, BQ(OPT-45), BQ(CRYO)
	123, 123(CRYO), 123(OPT-45), 123(OPT-46G)
	123-1+6, 123-1+6(OPT-45), 123-1+6(OPT-46G), 123-1+6+S, 123-1+6+S(OPT-40)
	1000HP, 1000HP(OPT-37), 1000HP(OPT-45), 1000HP(OPT-45G), 1000HP(CRYO)
	1000HP-1+6, 1000HP-1+8, 1000LP, 1000LP(OPT-45), 1000LP(OPT-46G)
	6987
	8310HP, 8310HP-1+6, 8310HP-1+8, 8310LP, 8311HP, 8311LP
	345, 345(OPT-45)
	BA1/BL1, PA1/PL1
	C-BPV, C-PRV, C-CS
	D, D(CRYO), D(OPT-37), D(OPT-20), D(OPT-45)
	DL, DL(LCC), DL(OPT-45)
	BR, BR(CRYO)
	HP, HP(LCC), HP(OPT-45), HP(OPT46G), HP-1+6+S(OPT-40), HP-1+6+S
	P1, P2, P3, P4, P5, P7
	B2, B7
	POSR-1, POSR-2
	5200P, 5300P
	135
	NW-PL, NW-SO
	CG-PILOT
	FG1
REGULATORS	RANGER, 987, PREMIER
	964, 521, 988, 988-MB, 989
	2296/2296HF
	SCV-30, SCV-S
TANK BLANKETING	8700, 8910, 8920, 8930, 8940
	2100, 2199
	3100, 3200, 3300, 3400, 3500, 3600, 3700
	1078, 1088, 1100, 1049
	5100, 5200, 5400, 5500
	4100, 4200, 4300, 4400, 4500, 4600
MISC	764P/PD, 764-37, 764T

Cashco
P.O. Box 6
Ellsworth, KS 67439-0006
PH (785) 472-4461
Fax. # (785) 472-3539
www.cashco.com
email: sales@cashco.com
Printed in U.S.A. IOM-POSR-2

Cashco GmbH
Handwerkerstrasse 15
15366 Hoppegarten, Germany
PH +49 3342 30968 0
Fax. No. +49 3342 30968 29
www.cashco.com
email: germany@cashco.com

Cashco do Brasil, Ltda.
Al.Venus, 340
Indaiatuba - Sao Paulo, Brazil
PH +55 11 99677 7177
Fax. No.
www.cashco.com
email: brazil@cashco.com