



# MODEL DA6

## DA6 - DIRECT-ACTING, PRESSURE LOADED BACK PRESSURE REGULATOR

### SECTION I

#### I. DESCRIPTION AND SCOPE

The Model DA6 is a pressure loaded back pressure regulator used to control upstream (inlet or P1) pressure. Sizes are 1/2" (DN15), 3/4" (DN20), 1" (DN25), 1 1/4" (DN32), 1 1/2" (DN40), 2" (DN50), 3" (DN80) and 4" (DN100). With proper trim utilization, the unit is suitable for liquid, gaseous, or steam service. Typically installed in a more common "reverse" flow direction arrangement that is balanced (to outlet). Refer to Technical Bulletin DA6-TB for design conditions and selection recommendations. (**NOTE:** This product was formerly identified as a Model D6; a Model DA6 and D6 are one and the same product.)

### SECTION II

#### II. REFERENCES

Refer to Technical Bulletin DA6-TB and DAG-TB for technical specifications of a Model DA6 regulator.

#### ABBREVIATIONS

CCW	–	Counter Clockwise
CW	–	Clockwise
ITA	–	Inner Trim Assembly

### SECTION III

#### III. INSTALLATION

1. Install per direction of flow arrow indicated on body, or "IN" and "OUT" markings.
2. Regulator may be rotated around pipe axis 360 degrees. For ease of maintenance, the recommended position is with the cover dome (25) upwards. In liquid service it is recommended that the cover dome (25) be oriented downwards, and that a customer supplied and installed vent valve be provided at the external sensing connection to bleed-off trapped gas/air under the diaphragm during initial startup.
3. Provide space below, above, and around regulator for removal of parts during maintenance.
4. Install block valves and pressure gauges to provide means for adjustment, operation, bypass, or removal of the regulator. A pipeline strainer is recommended before inlet to remove typical pipeline debris from entering valve and damaging internal "soft goods", primarily the dynamic side seal and V-TFE seat when applied.
5. Upstream Sensing Installation Considerations – Internal or External Sensing:
  - a. The regulator may be installed with internal or external sensing. Unless otherwise specified,

the regulator is supplied by factory with internal sensing. The regulator may be converted in the field to external sensing. (See Section VII Maintenance, Part H – Converting Internal/ External Sensing.)

- b. Reference DAG-TB, Table DAG-12 for recommendations for applying external pressure sensing.
- c. For internal sensing, no external line is required. For external sensing, use an external control line. The line is connected from the port 1/4" (DN8) NPT tap (Port 5 – See Fig. 5) on the side of the body diaphragm flange to a pressure tap upstream of the regulator. Use 1/4" (6.4 mm) or 3/8" (9.5 mm) outer diameter tubing or 3/8" (DN10) pipe having an inner diameter equivalent to schedule 40 pipe.
- d. For condensable vapors (i.e. steam) slope the external sensing line downward 2 to 5 degrees to inlet piping to prevent water pockets, which allows the diaphragm chamber to always be self draining. The external sensing line may be sloped upward for gas or liquid service; i.e. non-condensibles.



#### CAUTION

**Installation of adequate overpressure protection is recommended to protect the regulator from overpressure and all downstream equipment from damage in the event of regulator failure.**




## CAUTION

**DO NOT HYDROSTATIC TEST THROUGH AN INSTALLED UNIT; ISOLATE REGULATOR FROM TEST. See Technical Bulletin DA6-TB, Table 1; Maximum  $P_1$  - Inlet Pressure levels for various diaphragm materials by valve body size. Higher pressures could cause internal damage. The nameplate indicates the Inlet and Outlet pressure and temperature ratings.**



## CAUTION

**For welded installations, all internal trim parts, seals and diaphragm(s) must be removed from regulator body prior to welding into pipeline. The heat of fusion welding will damage non-metallic parts if not removed. NOTE: This does not apply to units equipped with extended pipe nipples.**



## CAUTION

**In the event of diaphragm failure, the process fluid will mix with the loading fluid.**

## SECTION IV

### IV. PRINCIPLE OF OPERATION

1. When a loading pressure –  $P_{Load}$  – is applied to the top side of a diaphragm, the inlet controlled pressure –  $P_1$  – will balance at approximately 0.96–0.98 of the loading pressure –  $P_L$  – for the standard flow direction, and at 0.98–1.0 of the loading pressure –  $P_L$  – for the reverse flow direction. **NOTE:** Fluctuations in the  $P_2$  – Outlet Pressure will cause a deviation in pressure setpoint –  $P_{SP}$  – the “crack-open” pressure for the standard flow direction. This deviation is compensated away for the reverse flow direction.
2. Movement occurs as pressure variations register

on the diaphragm. The registering pressure is the inlet,  $P_1$ , or upstream pressure. The loading pressure fluid opposes diaphragm movement. As inlet pressure increases, the diaphragm pushes up, opening the port; as inlet pressure decreases, the loading pressure pushes the diaphragm down and the port opening closes.

3. A complete diaphragm failure will cause the regulator to fail closed if in the standard flow direction variation, and tend to fail closed in the reverse flow direction but with seat leakage.
4. Loss of loading pressure while inlet pressure is imposed will cause valve to fail open.

## SECTION V

### V. STARTUP

1. Start with the block valves closed.
2. Adjust the loading system pressure control device so that main valve is trying to be controlled at 0 psig pressure.

3. Crack open manual bypass valve. Initially pressurize system while simultaneously controlling  $P_1$  pressure through manual actuation of bypass valve.
4. If it is a “hot” piping system, and equipped with a bypass valve, slowly open the bypass valve to preheat the system piping and to allow slow expansion of the piping. Ensure proper steam trap operation if installed. Closely monitor inlet (upstream) pressure via gauge to ensure not over-pressurizing. **NOTE:** If no bypass valve is installed, extra caution should be used in starting up a cold system; i.e. do everything slowly.



## CAUTION

**Do not walk away and leave a bypassed regulator unattended!**

5. Open the outlet (downstream) block valve.
6. Slowly open the inlet (upstream) block valve to about 25% open, observing the inlet (upstream) pressure gauge. The regulator should be flowing. Adjust the loading system pressure control device setpoint pressure upwards until the main valve flow is shutoff. Observe the inlet pressure gauge to ensure not over pressurizing.
7. Continue to open inlet block valve until at least 50% open. Set loading system pressure control device upwards to approximate 80% desired main valve pressure level.
8. Fully open inlet block valve.
9. Begin to slowly close the bypass valve if installed.
10. Develop system flow to a level near its expected normal rate, and reset the regulator set point by adjusting the loading system pressure control set point to the desired level.
11. Reduce system flow to a minimum level and observe pressure set point. Inlet pressure will decrease from the set point of Step 10. The maximum build in inlet pressure on increasing flow should not exceed 10%. If it does, consult factory.

## SECTION VI

### VI. SHUTDOWN

1. Shutoff auxiliary loading pressure source.
2. Shutoff inlet block valve.
3. Shutoff the outlet block valve.
4. Relieve the trapped upstream and downstream pressure and loading pressure.
5. The regulator may now be removed from the pipeline or disassembled for inspection and preventative maintenance while in-line.

## SECTION VII

### VII. MAINTENANCE


#### A. General:

1. The regulator may be serviced without removing the regulator from pipeline. The regulator is designed with quick-change trim to simplify maintenance.
2. Record the nameplate information to requisition spare parts for the regulator. The information should include: size, Product Code, and Serial Number.
3. Refer to Section VIII for recommended spare parts. Only use original equipment parts supplied by Cashco for rebuilding or repairing regulators.
4. Owner should refer to owner's procedures for removal, handling, cleaning and disposal of nonreusable parts, i.e. gaskets, etc.  
**NOTE:** On regulators originally supplied as "oxygen clean" – Opt-55, maintenance must include a level of cleanliness equal to Cashco cleaning standard #S-1134.
5. The Inner Trim Assembly (ITA) is removed and replaced in the body (23) as an assemblage of parts. The ITA consists of the following parts:


Item No.	Dynamic Side Seal Type	Part Description
7	All	Diaphragm Cap Screw
7	All	Diaphragm Lock Nut
8	All	Upper Diaphragm Pressure Plate
9	All	Diaphragm(s)
10	All	Lower Diaphragm Pusher Plate
13	All	Piston/Guide Bearing✓
14	All	Stem Seals
14.1	All	Upper Stem Seal
14.2	All	Middle Stem Seal
14.3	All	Lower Stem Seal✓
14.4	All	Lower Pusher Plate Gasket
20	All	Valve Plug
27	All	Dynamic Side Seal *
27.1	CP	TFE Cap Seal
27.2	CP	O-ring Energizer/Seal
27.3	UC	U-Cup Seal w/Metal Energizer
27.5	PR	Piston Ring Seal
27.6	PR	Piston Ring SST Energizer
28	All	Seat Disc
29	All	Seat Disc Washer
30	All	Seat Disc Nut

\* Possible option is with NO dynamic side seal.  
✓ 2-1/2" thru 4" body sizes only.


A detailed view of the dynamic side seal parts is shown in Figure 1 on the next page.




**Type CP**— TFE Cap Dynamic Seal



**Type PR** — PRA Dynamic Seal



**Type UC** — U-Cup Dynamic Seal



**Type NO** — No Dynamic Seal

**Figure 1: Dynamic Side Seals**

## B. Main Valve Disassembly:

### WARNING


**SYSTEM UNDER PRESSURE. Prior to performing any maintenance, isolate the regulator from the system and relieve all pressure. Failure to do so could result in personal injury.**

1. Shut down the system in accordance with Section VI.
2. Disconnect the external sensing line, if installed.
3. Though it is possible to disassemble the valve unit while installed in a pipeline, it is recommended that maintenance be done in a shop when possible. The descriptions hereafter will assume shop disassembly. Remove valve from pipeline.
4. Place the valve unit in a vise with the cover dome (25) upwards.
5. Loosen the diaphragm flange bolts (11) and nuts (12) uniformly.
6. Place matchmarks on body (23) and cover dome (25) flanges. Completely remove bolting (11,12). Remove the cover dome (25).
7. Grasp opposite edges of diaphragm (9) and withdraw the ITA from within the cage (19). Set the ITA aside.
8. Evenly loosen the cage cap screws (18) in single revolution increments until fully loosened; remove cage cap screws (18).
9. Pull cage (19) up and out of body.
10. Remove o-ring cage seal (15).
11. Remove lower cage gasket (21).
12. If supplied, remove internal sensing drilled plug (32) using 5/32" (4 mm) Allen key wrench. **NOTE:** Valves with "Large Internal Sensing" will not be equipped with any plug (32,33).
13. For metal diaphragm constructions, remove diaphragm gasket (37) from body (23) diaphragm flange.
14. Remove body (23) from vise. Solvent clean all removed metal parts.


## C. Disassembly of the ITA:

1. Body Sizes 1/2" – 2". (See Figures 2 thru 5):
  - a. Obtain two pieces of square-section barstock with a 3/8" - 7/16" dimension, approximately 2 inches long.
  - b. Place plug into a vise using the bars of a. above positioned on "flats" located on plug (20) to prevent vise jaw marks from direct surface contact with the plug (20). Orient with diaphragms on topside.
  - c. Sizes 1/2" – 1": Remove diaphragm locknut (7) by rotating CCW.  
Sizes 1-1/4" – 2": Remove diaphragm cap screw (7) by rotating CCW.
  - d. Remove upper diaphragm pressure plate (8).
  - e. Remove diaphragm(s) (9, 9.1, 9.2, 9.9). Examine diaphragm(s) to determine whether failed; determine if operating conditions are exceeding pressure drop or temperature limits.
  - f. For composition diaphragm construction, remove upper stem seal (14.1).
  - g. For metal diaphragm construction, remove lower pusher plate gasket (14.4).
  - h. Remove lower diaphragm pusher plate (10).
  - i. Remove middle stem seal (14.2).
  - j. Remove plug (20) from vise, rotate end-for-end, and resecure in vise using same metal bars of a. above.
  - k. Loosen seat nut (30) CCW (viewed from above) approximately two (2) revolutions.
  - l. Remove assembly (20, 27, 28, 29, 30) from vise. Complete removal of seat disc nut (30), seat disc washer (29), and seat disc (28).
2. Body Sizes 2-1/2" – 4". (See Figure 6):
  - a. Place seat disc nut (30) into a vise with the plug (20) oriented vertically. Do NOT over-tighten nut (30) in vise.
  - b. Place closed-end hex wrench onto diaphragm locknut (7). Place socket wrench on 3/4" hex upper end of plug (20). Loosen diaphragm locknut (7) while holding plug (20) from rotating by socket wrench. Remove diaphragm locknut (7) after fully loosened and socket wrench is removed.
  - c. Remove upper diaphragm pressure plate (8).
  - d. Remove diaphragm(s) (9, 9.1, 9.2, 9.9). Examine diaphragm(s) to determine whether failed; determine if operating conditions are exceeding pressure drop or temperature limits.







**Figure 2: Body Sizes**  
1/2" – 1", Composition Diaphragm




**Figure 3: Body Sizes**  
1/2" – 1", Metal Diaphragm



**Figure 4: Body Sizes**  
1-1/4" – 2", Composition Diaphragm



**Figure 5: Body Sizes**  
1-1/4" – 2", Metal Diaphragm



**Figure 6: Body Sizes**  
2-1/2" – 4", Composition Diaphragm

- e. Remove upper stem seal (14.1).
  - f. Remove lower diaphragm pusher plate (10).
  - g. Remove middle stem seal (14.2).
  - h. Remove piston/guide bearing (13) with dynamic side seal (27) in place.
  - i. Remove lower stem seal (14.3).
  - j. Place socket wrench on upper end of plug (20) as in Step b. above. Rotate plug (20) CCW (viewed from above) to loosen seat disc nut (30). Once nut (30) is loosened, remove partial assembly (20, 27, 28, 29, 30) from vise. Complete removal of seat disc nut (30), seat disc washer (29) and seat disc (28).
3. Examine the components (27.1, 27.2, 27.3, 27.4, 27.5, 27.6) of the dynamic side seal (27) to determine if significant leakage was occurring. If the dynamic side seal (27) shows signs of significant leakage, determine if operating conditions are exceeding pressure, pressure drop, or temperature limits.

Remove dynamic side seal (27) components from plug (20) for sizes 1/2" – 2", or from piston/guide bearing (13) for sizes 2-1/2" – 4". Special care should be taken when using "tools" to remove the components to ensure that no scratches are imparted to any portion of the plug (20) or piston/guide bearing (13) groove.

4. Solvent clean all metal parts to be reused.

#### D. Inspection of Parts:

1. After inspection, remove from the work area and discard the old "soft goods" parts (i.e. o-rings, diaphragms, seals, etc.). Metal diaphragms should be replaced. These parts MUST be replaced with factory supplied new parts.
2. Inspect the metal parts that will be reused. The parts should be free of surface contaminants, burrs, oxides, and scale. Rework and clean

the parts as necessary. Surface conditions that affect the regulator performance are stated below; replace parts that can not be reworked or cleaned.

3. QC Finish & Dimensional Requirements:
  - a. Valve plug (20);
    1. No major defects on plug's (20) bottom guide spindle, or at guide area near dynamic seal groove.
  - b. Cage (19);
    1. 16 rms finish on cylinder bore. No "ledges" formed due to wear from moving dynamic side seal (27).
    2. 16 rms finish on its seating surface for tight shutoff.
  - c. Lower guide bushing (24);
    1. 16 rms finish on bore.
    2. Max 0.015 inch (0.38 mm) clearance between valve plug (20) spindle and lower guide bushing (24).
  - d. Internal sensing drilled plug (32);
    1. Ensure that bore is minimum 0.125 inch (3.20 mm). Drill out as required.
  - e. Piston/Guide Bearing (13) (2-1/2"-4" only);
    1. No defects at guide area near dynamic seal groove.
4. Staging Material for Reassembly.
  - a. Inspect and clean parts, as necessary, from the spare parts kit. (See Article VII.A.4. comments concerning cleaning for oxygen service.)
  - b. Lay out all the regulator parts and check against the bill of material.

#### E. Reassembly of the ITA:

1. Position valve plug (20) with seat disc-end upwards. Place new seat disc (28) into recess of lower end of valve plug (20) properly oriented.
2. Position seat disc washer (29) next to seat disc (28).
3. Engage seat disc nut (30) to secure washer (29) and seat disc (28) to valve plug (20). Firmly hand-tighten.
4. Body Sizes 1/2" thru 2":
  - a. Using the two square-section metal bar-stock pieces of VII.C.1.a., clamp the plug (20) into a vise with the plug's (20) spindle pointed upwards.
  - b. Using a torque wrench, tighten the seat disc nut (30) to 20 – 35 ft-lbs. by rotating CW.

- c. Remove assembly (20, 28, 29, 30) from vise and rotate end-for-end and resecure in vise using same metal bars.

5. Body Sizes 2-1/2" thru 4":
  - a. Orient plug (20) with upper end upwards, place into a vise, grasping the seat disc nut (30); tighten the vise lightly, only enough to "hold" the plug (20) from rotating out of the vise. **Caution:** Over-tightening the vise can distort the seat disc nut (30) and give bad final torque values.
  - b. Place a torque wrench on the 3/4" hex upper end of the plug (20); tighten the seat disc nut (30) to 40 – 60 ft-lbs. by rotating CW.
6. Installation of dynamic side seal (27) (See Figure 1): (**NOTE:** Dynamic side seal (27) for sizes 2-1/2" – 4" is located on the piston/guide bearing (13). The dynamic side seal can be installed on a workbench without need of a vise.)
  - a. Type CP:
    1. Stretch o-ring energizer/seal (27.2) over lower circumference of valve plug (20), taking care not to "cut" o-ring energizer/seal (27.4). Using thumbs, work the o-ring energizer/seal (27.4) up and into the groove of the valve plug (20). **NOTE:** A very slight amount of fluid and elastomer compatible lubricant is recommended as an installation aid. DO NOT "ROLL" O-RING.
    2. Position TFE cap seal (27.1) ring with rectangular cross-section at lower end of valve plug (20). Stretch cap seal (27.1) over lower end of valve plug (20) using thumbs to work the cap seal (27.1) onto the valve plug (20). DO NOT USE A TOOL FOR THIS STEP. Continue pressing cap seal (27.1) upwards towards the groove until the cap seal (27.1) "snaps" into the groove of the valve plug (20).
  - b. Type PR:
    1. Wrap corrugated metal piston ring energizer (27.6) over lower circumference groove of valve plug (20). Using thumbs work the energizer (27.6) into the valve plug (20) groove.
    2. Spread a piston ring seal (27.5) and slide over lower circumference groove of valve plug (20), taking care not to

"cut" piston ring seal (27.5). Using thumbs, work the piston ring seal (27.5) into the groove of the valve plug (20). Repeat this procedure with a second piston ring seal (27.5). Orient/rotate the "splits" in piston ring seals (27.5) 180° across from each other.

c. Type UC:

1. Stretch u-cup seal (27.3) over upper circumference of valve plug (20), taking care not to "cut" u-cup seal (27.3) on the protruding shelf that is part of the valve plug's (20) groove. Ensure that the u-cup seal (27.3) is oriented with the center-open-upwards as shown in Figure 1, as the u-cup seal (27.3) depends upon the P1-Inlet Pressure to pressure activate the seal for proper sealing action.

d. Type NO:

1. For "standard" flow direction applications, it is not absolutely required that a dynamic side seal (27) be installed. (When included with the dynamic seal (27), better guiding of valve plug (20) results.) Type "NO" dynamic seal (27) means NO dynamic seal.
2. The more common "Reverse" flow direction always requires a dynamic side seal (27).

7. Place fluid compatible thread anti-seize, Locktite Corp., "Nickel Anti-Seize", or equal on threaded portion of diaphragm cap screw (7), sizes 1-1/4" and 1-1/2"; or, threaded post portion of valve plug (20), sizes 1/2" – 1" and 2-1/2" – 4". (**NOTE:** Valves cleaned for oxygen service should use Fisher Scientific Co., "Fluorolube GR-362", or equal.)

8. Body sizes 2-1/2" thru 4":

- a. Place o-ring lower stem seal (14.3) over upper-end of plug (20) and into groove on plug (20).
- b. Place properly oriented piston/guide bearing (13) over upper-end of plug (20) and into position on plug (20).
- c. Place o-ring middle seal (14.2) over upper-end of plug (20) and into groove of piston/guide bearing (13).

9. Body sizes 1/2 thru 2":

Place new o-ring middle stem seal (14.2) into groove of valve plug (20) upper surface.

10. Position lower diaphragm pusher plate (10)

on/over upper end of valve plug (20) properly oriented. For composition diaphragm construction the "tongue and groove" "ridge" should be on upper side, "flat" side downwards. For metal diaphragm construction the "rounded" surface of the lower diaphragm pusher plate (10) should be on upper side, "flat" side downwards.

11. For composition diaphragm construction, place new o-ring upper stem seal (14.1) on/over upper end of valve plug (20) and into groove of lower diaphragm pusher plate (10).

12. For metal diaphragm construction, place compatible gasket sealant on both sides and place new lower pusher plate gasket (14.4) on/over upper end of valve plug (20) and onto lower diaphragm pusher plate (10). (Gasket sealant is Federal Process Corp. "Gasolite", or equal.)

13. Position new diaphragm(s) (9) on/over upper end of valve plug (20). **NOTE:** For multiple diaphragms (9) that include TFE material, the TFE should be on the wetted side; for 6-ply elastomeric TFE diaphragm (9), stackup is TFE-TFE-HK-HK-TFE-TFE, beginning with the lower wetted diaphragm (9) first.

14. Position upper diaphragm pressure plate (8) on/over upper end of valve plug (20) properly oriented. For composition diaphragm construction the "tongue and groove" "ridge" should be on lower side, "flat" side upwards. For metal diaphragm construction the "rounded" surface of the upper diaphragm pressure plate (8) should be on lower side, "flat" side upwards.

15. a. Body sizes 1/2" thru 1": Engage diaphragm locknut (7) to threaded post portion of valve plug (20) and torque to 60-70 ft-lbs. by rotating CW.
- b. Body Sizes 1-1/4" and 1-1/2": Insert anti-seize coated diaphragm cap screw (7) through stacked parts (8, 9, 10, 14.1, 14.4) and into upper end of valve plug (20). Torque-tighten diaphragm cap screw (7) to 120-130 ft-lbs.
- c. Body Sizes 2-1/2" thru 4": Engage diaphragm locknut (7) to threaded post of valve plug (20) and wrench-tighten firmly. While restraining valve plug (20) from rotating by torque wrench on upper end 3/4" hex, use another wrench to tighten diaphragm locknut (7) to a torque of 180-200 ft-lbs.



16. This completes assembly of ITA; remove from vise.

#### F. Main Reassembly:

1. Place body (23) in a vise.
2. Reinstall internal sensing drilled plug (32) with compatible thread sealant.
3. Fit the o-ring cage seal (15) into its body (23) groove.
4. For metal diaphragm construction, place sealant ("Gasoil" or equal) on both sides of diaphragm gasket (37) and position on body (23) diaphragm flange.
5. Position properly oriented lower cage gasket (21) onto lower shelf of cage (19).
6. Insert cage (19) into body (23) recess. Properly align all cage bolt (18) holes as there is only one circumferential location possible for this alignment. Engage all of the cage bolts (18), then evenly screw in the cage bolts in one-half revolution increments, taking care NOT TO "COCK" THE CAGE (19) IN THE BODY. Torque the cage bolts (18) to 13-15 ft-lbs.

#### 7. Dynamic Side Seals:

- a. Type CP: Position the ITA's valve plug (20) lower end over and into upper end of cage (19) until the cap seal (27.1) edge touches the upper lip of the cage (19). While gently applying force to press the valve plug (20) into the cage (19), simultaneously use hand thumbs to lightly press the cap seal (27.1) inwards into the groove of the valve plug (20) until the cap seal (27.1) "slips into" the cage (19). DO NOT USE TOOLS, LUBRICANT, OR HEAVY FORCE TO ENGAGE THE CAP SEAL (27.1) INTO THE CAGE (19). Do not press inwards on the cap seal (27.1) too much or the cap seal (27.1) may slide out of its groove.
- b. Type PR: Position the ITA's valve plug (20) lower end over and into upper end of cage (19) until the lower piston ring seal (27.5) touches the upper lip of the cage (19). While gently applying force to press the valve plug (20) into the cage (19), simultaneously use fingers to lightly circumferentially press the first (lower) piston ring seal (27.5) inwards into the

valve plug (20) groove until the first piston ring seal (27.5) "slips into" the cage (19). Repeat for the second piston ring seal (27.5)

- c. Type UC: Position the ITA's valve plug (20) lower end over and into upper end of cage (19) until the cap seal (27.1) edge touches the upper lip of the cage (19). While gently applying force to press the valve plug (20) into the cage (19), simultaneously use hand thumbs to lightly press the u-cup seal (27.3) inwards into the groove of the valve plug (20) until the u-cup seal (27.3) "slips into" the cage (19). DO NOT USE TOOLS, LUBRICANT, OR HEAVY FORCE TO ENGAGE THE U-CUP SEAL (27.3) INTO THE CAGE.
  - d. Type NO: Position the ITA's valve plug (20) lower end over and into the cage (19), allowing plug (20) to enter fully.
8. For composition diaphragm construction, align diaphragm (9) bolt holes with body (23) diaphragm bolt holes.
  9. Aligning matchmarks and bolt holes, place cover dome (25) onto body (23) diaphragm (9) flange.
  10. Reinstall all flange bolts (11) and nuts (12) with nameplate (99) located under one bolt head. Hand-tighten nuts (12).
- NOTE:** If a six-ply diaphragm is being used, it is important that the diaphragm (9) is "pre-formed" – pulled together to remove as much entrapped air as possible and allow formation of a diaphragm (9) convolution. Starting with the body bolts and nuts (11,12) hand tightened, "preforming" can be accomplished by any one of the following techniques:
- a. Apply 30-50 psig pressure to the valve inlet and the valve outlet.  
OR
  - b. Block the valve inlet and outlet and apply 30-50 psig under the diaphragm through the 1/4" NPT (plugged) external pressure sensing connection on the valve diaphragm flange.  
AND
  - c. Leave pressure on through tightening of bolting (11,12).
11. Evenly tighten the body bolting (11,12) in an alternating cross pattern in one revolution increments to the following torque value:

Body Size		Torque	
in.	(mm)	ft-lb	(N-m)
1/2"-2"	(DN15-50)	30-35	(41-47)
2 1/2"-4"	(DN65-100)	45-50	(61-69)

If supplied, remove pressure of previous Step 10.

#### G. Units with Supported Diaphragm Designs:

1. A supported diaphragm (9) construction is designated as Opt-81 High Inlet Pressure. Both upwards and downwards directions are protected against pressure reversal; i.e. pressure on one side of diaphragm (9) with no pressure on other side of diaphragm (9).
2. Body Sizes 2" and Smaller; Composition and Metal Diaphragm. (See Figure 7.)
  - a. Body (23) is specially machined with a shelf to capture a lower diaphragm support ring (35).
  - b. Cover dome (25) is specially machined to provide a surface for the upper diaphragm (9) support. Lower diaphragm support ring (35) is captured by its location. Upon removal of cover dome (25) and diaphragm (9), the lower diaphragm support ring (35) can be lifted upwards and out of the body (23) cavity.
  - c. Reinstallation is a reversal of Step b. above.
3. Body Sizes 2" and Smaller; Metal Diaphragm. (See Figure 8.)
  - a. Body (23) is specially machined with a shelf to capture a lower diaphragm support ring (35) and a groove for lower o-ring diaphragm seal (65).
  - b. Cover dome (25) is specially machined to provide a surface for the upper diaphragm (9) support and a groove for upper o-ring diaphragm seal (65). Lower diaphragm support ring (35) is captured by its location. Upon removal of cover dome (25) and diaphragm (9), the lower diaphragm support ring (35) can be lifted upwards and out of the body (23) cavity.
  - c. Dual o-ring seals (65) replace the diaphragm gasket (37) normally supplied with standard metal diaphragm construction; i.e. non-Opt-81.
  - d. Reinstallation is a reversal of Step b. above.
4. Body Sizes 2-1/2" and Larger; Composition Diaphragm. (See Figure 9.)
  - a. Body (23) is a standard body (23).
  - b. Cover dome (25) is specially machined to provide a surface for the upper diaphragm (9) support.
  - c. When disassembling valve unit, after lower

diaphragm pusher plate (10) is removed, access is provided to extended-length cage cap screws (18). When screws (18) are removed, both the cage (19) and the lower diaphragm support ring (35) are loose, and can be lifted upwards and out of the body (23) cavity.

- d. Upon reassembly of valve unit, after cage (19) is positioned in body (23), lower diaphragm support ring (35) is positioned with cage (19) flange bolt holes (only one orientation possible) prior to engagement and tightening of cage cap screws (18). Torque screws to levels indicated in Sub-Section F.7.i., this Section.

#### H. Converting Internal/External Sensing:

1. Disassemble the regulator and remove the diaphragm(s) (9) according to Steps 1-12 in Part B – Main Regulator Disassembly.
2. To convert from internal to external sensing, remove the drilled pipe plug (32) and install a solid pipe plug. Reverse this step for converting from external to internal sensing.
3. Reassemble the regulator according to Part F – Main Regulator Reassembly.

#### I. Pressure Testing:

1. If a hydrostatic pressure test is performed, pressure must be applied to all three of cover dome (25), inlet and outlet of body at the same level.
2. Inboard Leakage Test (Seat + Dynamic Seal Leakage).


### CAUTION

**DO NOT HYDROSTATICALLY TEST WITHOUT COVER DOME PRESSURIZED. NOT ADHERING WILL DO PHYSICAL INTERNALS DAMAGE THAT COULD RENDER THE UNIT INOPERABLE.**


- a. Release all loading pressure in cover dome.
- b. Pressurize inlet to 30 psig with air, GN<sub>2</sub>.
- c. Tube outlet to a beaker of water to observe number of escaping gas bubbles.

Inboard leakage path may be via plug/seat or dynamic side seal.


3. Pressure Containment Test.
  - a. Pressurize inlet, outlet and cover dome to 150 psig with air or GN<sub>2</sub>.



**Figure 7:** Opt-81 — Composition Diaphragm Construction, 2" and Smaller



**Figure 8:** Opt-81 — Metal Diaphragm Construction, 2" and Smaller



**Figure 9:** Opt-81 — Composition Diaphragm, 2-1/2" – 4"

- b. Soap solution test all external leak points; plugged connections, diaphragm flange and diaphragm bolting.
4. Excessive leakage will require disassembly, examination of sealing elements, correction of problem, reassembly and retesting.

**NOTE:** This valve is NOT a bubble-tight shutoff device. See DAG-TB, Table DAG-10 for leakage classes.

## SECTION VIII

### VIII.PRESSURE LOADING

1. Loading pressure can be supplied using various schemes. Please reference **LOADING SYSTEMS** for the schematics of these various schemes, including:
  - pressure unloading using BPV
  - pressure loading using PRV
  - pressure loading using I/P transducer

## SECTION IX

### IX. TROUBLE SHOOTING GUIDE

When trouble shooting this regulator there are many possibilities as to what may be causing problems. Many times, the regulator itself is not defective, but one or more of the accessories may be. Sometimes the process may be causing difficulties.

The key to efficient trouble shooting is information and communication. The customer should try to be as precise as possible in their explanation of the problem, as well as their understanding of the application and operating conditions.

It is imperative the following information be provided by the customer:

- Fluid (with fluid properties)
- Range of flow rate
- Range of inlet pressure
- Range of outlet pressure
- Range of fluid temperature
- Range of ambient temperature

Pressure readings should be taken at every location that pressure plays a role - i.e., regulator inlet (as close as possible to inlet port), regulator outlet (as close as possible to outlet port), etc.

Following are some of the more common complaints along with possible causes and remedies.

### 1. Erratic regulation, instability or hunting.

Possible Causes	Remedies
A. Sticking of internal parts	A. Remove internals, clean, and if necessary, replace.
B. Load changes are too quick for system	B. Convert to external sensing (if necessary) and install an orifice or needle valve in external sensing line.
C. Oversized regulator	C. Check actual flow conditions; resize regulator for minimum and maximum flow; if necessary, replace with smaller regulator.

### 2. Erratic regulation, instability or hunting (liquid service).

Possible Causes	Remedies
A. Air trapped under diaphragm	A. Install valve on external sensing port and bleed off air. (Install regulator upside down to help prevent reoccurrence.)

### 3. Upstream pressure too high.

Possible Causes	Remedies
A. Supply pressure is down (confirm on pressure gauge).	A. Increase supply pressure.
B. Undersized regulator.	B. Check actual flow conditions; resize regulator for minimum and maximum flow; if necessary, replace with larger regulator.
C. Pressure loading system pressure restricted.	C1. Clean restriction or bleed orifices. C2. Clean filter(s). C3. Clean loading pressure control device.
D. Faulty loading pressure control device.	D. Replace/repair loading pressure control device.

#### 4. Diaphragm continually breaks (steam service regulators).

Possible Causes	Remedies
A. Stem seals (14) which protect fluorocarbon elastomer in diaphragm assembly may have deteriorated.	A. Replace with new stem seals (14).
B. Diaphragm nut (7) may not be torqued to proper value.	B. Confirm torque value in accordance with Section VII, paragraph E-13.
C. Diaphragm too stiff causing it to crack in service.	C. Follow proper preforming and air evacuation techniques during diaphragm installation in accordance with Section VII, paragraph F-10.

#### 5. Diaphragm continually breaks (all regulators).

Possible Causes	Remedies
A. Differential pressure across diaphragm may have exceeded limits. (See Table 1 in Tech Bulletin DA6-TB.)	A1. Be aware of limits as well as where the various pressures are acting. Install pressure safety equipment as necessary. A2. Consider if full diaphragm support, Opt-81, should be added.

#### 6. Leakage at diaphragm flange.

Possible Causes	Remedies
A. Body bolts not torqued properly.	A. Torque to proper value (see Section VII, paragraph F-11).
B. Pressures at diaphragm may be too high for regulator design.	B. Consult factory.

#### 7. Leakage across seat.

Possible Causes	Remedies
A. Contamination (debris) in regulator.	A. Remove internals, clean, and if necessary, replace sealing and seating elements. *
B. Oversized regulator; valve plug operates directly next to seat.	B. Check actual flow conditions; resize regulator for minimum and maximum flow; if necessary, replace with smaller regulator.
* Excess seat leakage may be diagnosed when a failure of the dynamic side seal has occurred. Inspect <u>both</u> potential internal leak paths.	



## SECTION X

### X. ORDERING INFORMATION

#### NEW REPLACEMENT UNIT vs PARTS "KIT" FOR FIELD REPAIR

To obtain a quotation or place an order, please retrieve the Serial Number and Product Code that was stamped on the metal name plate and attached to the unit. This information can also be found on the Bill of Material ("BOM"), a parts list that was provided when unit was originally shipped. (Serial Number typically 6 digits). Product Code typical format as follows: (last digit is alpha character that reflects revision level for the product).

□□□□ - □□□□ 7 - □□□□□□□□□□

#### NEW REPLACEMENT UNIT:

Contact your local Cashco Sales Representative with the Serial Number and Product code. With this information they can provide a quotation for a new unit including a complete description, price and availability.



#### CAUTION

**Do not attempt to alter the original construction of any unit without assistance and approval from the factory. All purposed changes will require a new name plate with appropriate ratings and new product code to accommodate the recommended part(s) changes.**


#### PARTS "KIT" for FIELD REPAIR:

Contact your local Cashco Sales Representative with the Serial Number and Product code. Identify the parts and the quantity required to repair the unit from the "BOM" sheet that was provided when unit was originally shipped.

**NOTE:** *Those part numbers that have a quantity indicated under "Spare Parts" in column "A" reflect minimum parts required for inspection and rebuild, - "Soft Goods Kit". Those in column "B" include minimum trim replacement parts needed plus those "Soft Goods" parts from column "A".*

If the "BOM" is not available, refer to the cross-sectional drawings included in this manual for part identification and selection.

A Local Sales Representative will provide quotation for appropriate Kit Number, Price and Availability.



Model DA6  
Composition Diaphragm  
FTO – Reverse Flow Direction

Item No.	Description	Item No.	Description
7	Diaphragm Cap Screw or Diaphragm Lock Nut	23	Body
8	Upper Diaphragm Pressure Plate	24	Lower Guide Bushing
9 ‡	Diaphragm	25	Cover Dome
9.1	Diaphragm (Material #1)	26	Tap Plug (Not Shown)
9.2	Diaphragm (Material #2)	27 ‡	Dynamic Side Seal
9.9	Diaphragm TFE Cover	27.1	TFE Cap Seal
10	Lower Diaphragm Pusher Plate	27.2	O-ring Energizer/Seal
11	Flange Bolts	27.3	U-cup with Metal Energizer
12 *	Flange Bolting Nuts	27.5	Piston Ring Seal
14 ‡	Stem Seal	27.6	Piston Ring Energizer
14.1	Upper Stem Seal	28 ‡	Seat Disc
14.2	Middle Stem Seal	29	Seat Disc Washer
15 ‡	Cage Seal	30	Seat Disc Nut
18	Cage Cap Screws	32	Internal Sensing Plug (External Sensing Only)
19	Cage	33	Internal Sensing Drilled Plug (Internal Sensing Only)
20	Valve Plug	99	Nameplate
21 ‡	Lower Cage Gasket		


\* Not required on 2" CS & SST Body Material.

See Figures 2 – 6 for alternate plug constructions.

‡ Recommended Repair Parts

For sizes 2-1/2" thru 4", see diaphragm/plug construction in Figure 6.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such product at any time without notice. Cashco does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Cashco product remains solely with the purchaser.



Model DA6  
Metal Diaphragm  
FTC – Standard Flow Direction

Item No.	Description	Item No.	Description
7	Diaphragm Lock Nut	24	Lower Guide Bushing
8	Upper Diaphragm Pressure Plate	25	Cover Dome
9 ‡‡	Diaphragm	26	Tap Plug
9.1	Diaphragm (Material #1)	27 ‡‡	Dynamic Side Seal
9.2	Diaphragm (Material #2)	27.1	TFE Cap Seal
9.9	Diaphragm TFE Cover	27.2	O-ring Energizer/Seal
10	Lower Diaphragm Pusher Plate	27.3	U-cup with Metal Energizer
11	Flange Bolts	27.4	O-ring Seal
12 *	Flange Bolting Nuts	27.5	Piston Ring Seal
14 ‡‡	Stem Seal	27.6	Piston Ring Energizer
14.2	Middle Stem Seal	28 ‡‡	Seat Disc
14.4	Lower Pusher Plate Gasket	29	Seat Disc Washer
15 ‡‡	Cage Seal	30	Seat Disc Nut
18	Cage Cap Screws	32	Internal Sensing Plug (External Sensing Only)
19	Cage	33	Internal Sensing Drilled Plug (Internal Sensing Only)
20	Valve Plug	37	Diaphragm Gasket
21 ‡‡	Seat Ring	99	Name Plate
23	Body		

\* Not required on 2" CS & SST Body Material.

See Figures 2 – 6 for alternate plug constructions.

‡‡ Recommended Repair Parts



IOM ADDENDUM:

ATEX DIRECTIVE 2014/34/EU and THE EQUIPMENT AND PROTECTIVE SYSTEMS INTENDED FOR USE IN POTENTIALLY EXPLOSIVE ATMOSPHERES REGULATIONS 2016

Cashco declares that the products listed in the table below has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres given in Annex II of the ATEX Directive 2014/34/EU and given in Schedule 1 of The Equipment and Protective Systems Indented for Use in Potentially Explosive Atmospheres Regulations 2016. Compliance with the Essential Health and Safety Requirements has been assured by compliance with EN ISO 80079-36:2016 and EN ISO 80079-37:2016. The product will be marked as follows:

  II 2 G  
Ex h IIB T6... T1 Gb  
1000ATEXR1 X

The 'X' placed after the technical file number indicates that the product is subject to specific conditions of use as follows:

1. The maximum surface temperature depends entirely on the operating conditions and not the equipment itself. The combination of the maximum ambient and the maximum process medium temperature shall be used to determine the maximum surface temperature and corresponding temperature classification, considering the safety margins described prescribed in EN ISO 80079-36:2016, Clause 8.2. Additionally, the system designer and users must take precautions to prevent rapid system pressurization which may raise the surface temperature of system components and tubing due to adiabatic compression of the system gas. Furthermore, the Joule-Thomson effect may cause process gases to rise in temperature as they expand going through a regulator. This could raise the external surface temperature of the regulator body and the downstream piping creating a potential source of ignition. Whether the Joule-Thomson effect leads to heating or cooling of the process gas depends on the process gas and the inlet and outlet pressures. The system designer is responsible for determining whether the process gas temperature may raise under any operating conditions.
2. Where the process medium is a liquid or semi-solid material with a surface resistance in excess of 1GΩ, special precautions shall be taken to ensure the process does not generate electrostatic discharge.
3. Special consideration shall be made regarding the filtration of the process medium if there is a potential for the process medium to contain solid particles. Where particles are present, the process flow shall be <1m/s (<3.3 ft/s) in order to prevent friction between the process medium and internal surfaces.
4. Effective earthing (grounding) of the product shall be ensured during installation.
5. The valve body/housing shall be regularly cleaned to prevent build up of dust deposits.
6. Regulators must be ordered with the non-relieving option (instead of the self-relieving option) if the process gas they are to be used with is hazardous (flammable, toxic, etc.). The self-relieving option vents process gas through the regulator cap directly into the atmosphere while the non-relieving option does not. Using regulators with the self-relieving option in a flammable gas system could create an explosive atmosphere in the vicinity of the regulator.
7. Tied diaphragm regulators with outlet ranges greater than 7 barg (100 psig) should be preset to minimize the risk that improper operation might lead to an outboard leak and a potentially explosive atmosphere.
8. All equipment must only be fitted with manufacturer's original spare parts.
9. Ensure that only non-sparking tools are used, as per EN 1127-1, Annex A.

	PRODUCT
	31-B, 31-N
	1164, 1164(OPT-45)
	1171, 1171(OPT-45), 1171(CRYO)
	2171, 2171(OPT-45), 2171(CRYO), 3171
	1465, 3381, 3381(OPT-45), 3381(OPT-40)
	4381, 4381(OPT-37), 4381(CRYO), 4381(OPT-45), 5381
	MPRV-H, MPRV-L
	PBE, PBE-L, PBE-H
	CA-1, CA-2
	CA1, SA1, CA4, SA4, CA5, SA5
	DA2, DA4, DA5, DA6, DA8
	DA0, DA1, DAP, SAP
	SLR-1, SLR-2, PTR-1
	ALR-1, ULR-1, PGR-1
	BQ, BQ(OPT-45), BQ(CRYO)
	123, 123(CRYO), 123(OPT-45), 123(OPT-46G)
	123-1+6, 123-1+6(OPT-45), 123-1+6(OPT-46G), 123-1+6+S, 123-1+6+S(OPT-40)
	1000HP, 1000HP(OPT-37), 1000HP(OPT-45), 1000HP(OPT-45G), 1000HP(CRYO)
	1000HP-1+6, 1000HP-1+8, 1000LP, 1000LP(OPT-45), 1000LP(OPT-46G)
	6987
	8310HP, 8310HP-1+6, 8310HP-1+8, 8310LP, 8311HP, 8311LP
	345, 345(OPT-45)
	BA1/BL1, PA1/PL1
	C-BPV, C-PRV, C-CS
	D, D(CRYO), D(OPT-37), D(OPT-20), D(OPT-45)
	DL, DL(LCC), DL(OPT-45)
	BR, BR(CRYO)
	HP, HP(LCC), HP(OPT-45), HP(OPT46G), HP-1+6+S(OPT-40), HP-1+6+S
	P1, P2, P3, P4, P5, P7
	B2, B7
	POSR-1, POSR-2
	5200P, 5300P
	135
	NW-PL, NW-SO
	CG-PILOT
	FG1
<b>REGULATORS</b>	
<b>CONTROL VALVES</b>	RANGER, 987, PREMIER
	964, 521, 988, 988-MB, 989
	2296/2296HF
	SCV-30, SCV-S
<b>TANK BLANKETING</b>	8700, 8910, 8920, 8930, 8940
	2100, 2199
	3100, 3200, 3300, 3400, 3500, 3600, 3700
	1078, 1088, 1100, 1049
	5100, 5200, 5400, 5500
	4100, 4200, 4300, 4400, 4500, 4600
<b>MISC</b>	764P/PD, 764-37, 764T

Cashco  
P.O. Box 6  
Ellsworth, KS 67439-0006  
PH (785) 472-4461  
Fax. # (785) 472-3539  
www.cashco.com  
email: sales@cashco.com  
Printed in U.S.A. DA6-IOM

Cashco GmbH  
Handwerkerstrasse 15  
15366 Hoppegarten, Germany  
PH +49 3342 30968 0  
Fax. No. +49 3342 30968 29  
www.cashco.com  
email: germany@cashco.com

Cashco do Brasil, Ltda.  
Al.Venus, 340  
Indaiatuba - Sao Paulo, Brazil  
PH +55 11 99677 7177  
Fax. No.  
www.cashco.com  
email: brazil@cashco.com